The ParticleScan® Lite

Description and Specifications

The ParticleScan' Lite Kit includes

- · ParticleScan Lite
- · Protective Carrying Case
- AC Adapter/Battery Charger
- · Purge Filter
- · Isokinetic Sampling Probe

ParticleScan' Lite Features:

- 1 Isokinetic Sampling Probe
- 2 Air Intake Nozzle
- 3 "Low Battery" Indicator
- 4 8-Digit LED Display
- 5 On/Off Switch
- 6 Input Socket for AC Adapter/Battery Charger



Specifications

Minimum sensitivity:

0.3 microns

Light Source:

laser diode

Measurement Unit:

Either particles per cubic foot or particles per litre

Sample Time:

2 seconds, updates every 2 sec.

Flow Rate: Size (HxWxD):

0.025 cubic foot per minute $205 \times 100 \times 55$ mm (8 x 4 x 2 inches)

Weight:

710 g (1.6 pounds)

Power:

120V or 230V AC adapter

Battery:

6 volt rechargeable Ni-MH pack

recharge time: ca. 4 hours operating time: up to 4 hours

Specifications are subject to change without notice.

The ParticleScan® Lite

Operating Instructions

1. How to charge the ParticleScan Lite

- To charge the ParticleScan Lite, connect the AC adapter to the input socket located on the side of the device. (Caution: Only use the supplied AC adapter. Other AC adapters may damage the ParticleScan Lite.)
- b. Fully charged, the ParticleScan Lite should provide approximately 4 hours of continuous operation.
- c. When the battery power level becomes low, the green 'Low Battery' indicator will flash. It takes approximately 4 hours to fully charge the ParticleScan Lite.

2. How to take airborne particle measurements

- a. Take the ParticleScan Lite out of the carrying case and remove the protective red rubber cap from the air intake nozzle located at the top of the ParticleScan Lite. (Note: Do not operate the ParticleScan Lite with the cap in place as this may damage the internal pump.)
- Connect the supplied isokinetic probe to the air intake nozzle with the attached plastic tube. The ParticleScan Lite is now ready for sampling.
- c. Turn ParticleScan Lite on with the On/Off switch located on the right side of the device. A humming sound indicates that the pump is drawing in air for sampling.
- Immediately after it is switched on, the instrument starts a short countdown until its first particle count. The particle count is updated every 2 seconds thereafter.
- e. Depending on the model, the particle count appearing in the display represents the concentration of particles
 (≥ 0.3 μm) per cubic foot or per litre of air. (Note: the measurement unit is stated underneath the LED Display.)
- f. To switch the ParticleScan Lite off, set the On/Off switch to the 'off' position. (**Note:** For storage and transport, the protective red rubber cap must always be placed over the air intake nozzle.)

3. Testing and cleaning the sensor

- After repeated readings in dusty or polluted environments, the particle sensor may accumulate contaminants.
 As a result, the particle readout may become inaccurate.
- To test the sensor, a purge filter is supplied with the ParticleScan Lite. Simply connect the plastic tube from the purge filter to the air intake nozzle and switch the ParticleScan Lite on.
 - i. If the particle count reaches zero after a few readings, the sensor is clean.
 - ii. If the particle count does not reach zero within a few minutes, this may be an Indication of sensor contamination. In such a case leave the ParticleScan Lite running for several hours with the purge filter attached. Should the readout then still not show a zero count, the ParticleScan Lite should be returned for cleaning and recalibration.
- c. Two basic steps can be taken to reduce the accumulation of contaminants on the sensor:
 - Measurements in very polluted environments should be avoided.
 - ii. The purge filter 'zero count' test should be performed regularly after a few hours of use.

4. Calibration and Service

The valid calibration period for laser particle counters is 1 year. Recalibration should be undertaken at yearly intervals to ensure continuous accurate and reliable performance. Contact your point of purchase for details.